

# DEHUMIDIFIER OPERATION MANUAL

## MODEL: A-ONE45L / A-ONE50L / A-ONE70L / A-ONE90L








1. ON/OFF Key
2. UP AND DOWN Key
3. PURGING Indicator
4. DEFROSTING Indicator
5. PURGE Key
6. HUMIDITY AND TIME Display
7. TIME Key
8. OPERATRING Indicator

### BEFORE OPERATION


- Place the dehumidifier up right for 30 minutes before switching it on. **This is necessary** to allow the refrigerant system to stabilise and avoid system damage.
- Make sure the drainage hose is attached and clear of any obstruction. The hose must not exceed a height of 1.5mtrs. Failure to do so may cause a water backup into the pump resulting in leakage.
- Place the dehumidifier in an enclosed area, as this creates a drying chamber. Close all doors, windows or areas that open to external areas to maximize the dehumidifier efficiency. Keep traffic through the area to a minimum.
- DO NOT allow the airflows to be obstructed.


### OPERATION

A.  ON/OFF: Press the ON/OFF key to turn unit ON.

B.  AND   
 -Press  or  key to set or adjust humidity in the range between 26% and 90%. (When the environmental humidity is below or at 26%, "CO" will be displayed.) Once the humidity reaches the set point, operation will pause and will continue when the humidity level increases.  
 - During operation the unit may also pause to "PURGE" the water.

C. When finished, turn off the unit by pressing the ON/OFF key. The water pump will continue for another 40s to drain the water and it will turn off automatically.  
 - **DO NOT** disconnect power until unit stops.

D.  Press the PURGE key if you want to drain the water manually at any time.

E.  Time Key is ONLY for operational time used.